



PRO-GAMING
MOUSE



M625PLUS
PMW3325&PAW3335

Thank you for choosing our gaming mouse. To ensure the optimum performance and safety, please read the user manual carefully before you use this product.

Package Content

Mouse × 1 Manual × 1 1.6m Type-C cable × 1

Compatibility

Compatible with Windows 7, Windows 8 and Windows 10
Notice: Optical mouse is suitable for many kinds of surface, like wooden, paper, cloth etc. But optical mouse is not available to use on glass or smooth rubber surface.

Keys Function



1.

User Manual

1. Charging method

Connecting Type C cable to the mouse and plug it into USB port. Then the LED light below scroll wheel will turn RED and the light will extinguish when the battery is full.

2. Wired/Wireless mode switching

Connecting the mouse to PC with type C, then the mouse entered in wired mode. Plug the receiver into device, turn on the mouse then it can enter in wireless mode.

3. Code matching in wireless mode

Press ①, ④ and ② in the same time for 3s can enter in code matching mode. Please insert the receiver within 10s when the mouse flashes blue. When the blue light turns to the floating RGB light and the mouse can work normally, it means code matching successfully. If not, please try again.

4. Light control hot key

Press ⑥+⑦ for 3s can turn off the light, the light will turn on when press ⑥+⑦ for 3s again.

5. DPI switching

Short press ⑤ to switch in the 5 DPI gears.

PMW3325: 400DPI (Red light) , 800 (Green light) , 1600 (Blue light) , 3200 (Purple light) , 5000 (Yellow light) ; the DPI defaults to 1600.

The corresponding light flashes 2 times then turn to the original light mode when DPI switching.

DPI driver available to adjust for 200-10000DPI, 100 per gear.

PMW3335: 400DPI (Red light) , 800 (Green light) , 1600 (Blue light) , 3200 (Purple light) , 5000 (Yellow light) ; the DPI defaults to 1600.

The corresponding light flashes 2 times then turn to the original light mode when DPI switching.

DPI driver available to adjust for 200-16000DPI, 100 per gear.

2.

6. Low voltage indication

The decorative light will extinguish when the voltage lower than 3.4V, the mouse still can work normally. The overall light flashes red indicates the mouse in low voltage condition, please charging in time.

Driver Instructions

1. Driver installation

Download the driver from DELUX website or get it from CD(optional) which in the package. You can set the light, DPI, parameter and macro after configuring the driver.

2. Driver setting

Open the driver setting interface (the device needs to be connected, otherwise the driver can't run) to set the light, DPI, parameter and macro. The menu is on top of the interface, and the driver is available for multi-group setting.

Notice: You can set the wired parameter in wired mode, but if you want to set wireless parameter, you need switch to the wireless mode.

A.Button setting

Click the set button on the right side of the interface, then you can set the left button, right button, middle button, forward button, backward button, scroll up button, scroll down button, triple shot, fire button, combination key, macro definition, disable button, DPI key, multimedia function, DPI lock or other functions. Click apply to complete the setting after the setting is successful.

3.



B. Light setting

Click "Lighting" to set the light effect. The mouse will show different light effect when you choose different light mode. User can adjust brightness, speed, color and other parameters by your ownself.

Click apply to complete the setting after the setting is successful.



4.

C. DPI setting

Click "DPI" to modify the settings of DPI gear, the corresponding light color and DPI value. Click apply to complete the setting after the setting is successful.

PMW3335: DPI: 100-16000



PMW3325 DPI: 200-10000



5.

D. Parameter setting

Click "Parameter" to set the movement speed, scroll wheel speed and double-click speed. And you can choose the corresponding rate of polling on the right side of the interface. Click apply to complete the setting after the setting is successful.



E. Macro setting

Click "Macro" to enter in the macro setting interface. First, create a macro name, then select it to click "start recording". You can input the button you need when recording, then click "stop recording". The operation instructions of import macro: Select the button you want to reset in button setting interface, then click "Macro definition" in the drop-down menu. Select the macro name, and click apply to complete the setting.

6.



7.






Геймърска
МИШКА



M625PLUS
PMW3325&PAW3335

Благодарим ви, че избрахте тази геймърска, кабелна мишка. Моля, прочетете ръководството на потребителя внимателно, преди да започнете да я използвате.

Съдържание на пакета:



Съвместимост с ОС:

Съвместима с ОС: Win 7/8/10, MacOS - само основни функции. Не е наличен софтуер.

Функции на клавишите:



①	Ляв бутон
②	Десен бутон
③	Fire бутон
④	Скролер
⑤	DPI бутон
⑥	Напред
⑦	Назад
⑧	On/Off бутон
⑨	Приемник

1.

1. Метод на зареждане

Свържете Туре-С кабела към мишката и USB порт на компютър. LED светлина под скролера ще свети в червено, докато се зарежда. Когато батерията се зареди ще светне в зелено.

2. Кабелен/безжичен режим

Свържете кабела на мишката към USB порт на компютър за жичен режим. Включете нано приемника в компютър за безжичен режим.

3. Сдвояване с код при безжичен режим

Натиснете ①, ④ и ② едновременно за 3 сек, за да влезете в режим на съвпадение на кодове. Моля, поставете приемника в рамките на 10 сек., когато мишката мига в синьо. Синята светлина се превърне в плаваща RGB светлина, мишката може да работи нормално - кода съвпада успешно. Ако не се получи, моля, опитайте отново.

4. Бутон за подсветката

Натиснете ⑥+⑦ за 3 сек. за включване на подсветката. За включване ги натиснете отново за 3 сек.

5. DPI режими

Натиснете бутон ⑤, за да превключите между 5 DPI. Сензор PMW3325: 400 DPI (червена светлина), 800 (зелена светлина), 1600 (синя светлина), 3200 (лилава светлина), 5000 (жълта светлина); DPI по подразбиране е 1600. Съответната светлина мига 2 пъти, след което превключете към оригиналния светлинен режим при превключване на DPI. Чрез драйвъра настройте от 200-10000 DPI, 100DPI на режим.

2.

6. Индикация за нисък заряд

Светлината ще изгасне, когато зарядът в батерията е по-нисък от 3.4V. Мишката все още може да работи нормално. Когато червена мигаща светлина се появи, означава, че батерията е с нисък заряд и трябва да я заредите.

Инструкции за драйвърите

1. Инсталиране
Изгледете драйвера от сайта или го вземете от компактдиска (по избор), който е в пакета. Можете да зададете светлина, DPI, параметър и макрос след конфигуриране на драйвера.
2. Настройка
Отворете интерфейса за настройка на драйвера, за да настроите светлината, DPI режимите и макросите. Менюто е в горната част на интерфейса и драйвърът е наличен за настройка.
Забележка: Можете да зададете кабелни настройки в кабелен режим, а за безжични настройки, трябва да преминете към безжичен режим.

Настройки на бутоните

Щракнете върху бутон за настройка от дясната страна на интерфейса, след което настройте ляв, десен бутон, скролер, напред, назад, бутон за превъртане нагоре, бутон за превъртане надолу, троен изстрел, бутон за огън, клавиш с комбинация, макро дефиниция, бутон за деактивиране, клавиш DPI, мултимедия, заключване на DPI или други функции. Изберете „Apply“, за да завършите настройките.

3.



Б. Настройки на подсветката

Щракнете върху „Lighting“, за да зададете светлинен ефект. Мишката ще покаже различни светлинни ефекти, когато изберете различен режим. Потребителят може да настрои яркост, скорост, цвят и други параметри. Щракнете върху „Apply“, за да завършите настройката.



4.

В. DPI настройки

Щракнете върху „DPI“, за да промените DPI настройките, съответната светлина, цвят и стойност на DPI. Щракнете върху „Apply“, за да завършите настройката.

Сензор: PMW3325



Г. Настройки на параметрите

Щракнете върху „Parameter“, за да зададете скоростта на движение, скоростта на колелото за превъртане и скорост на двойно щракване. И можете да изберете също Polling rate от дясната страна на интерфейса. Щракнете върху „Apply“, за да завършите настройките.

5.



Д. Макро настройки

Щракнете върху „Macro“, за да влезете в интерфейса за настройка на макроси. Създайте име на макрос, след което го изберете, за да щракнете върху „Start recording“. Можете да въведете бутон, от който се нуждаете, когато записвате, след това щракнете върху „спране на записа“. Инструкциите за работа на макроса за импортиране: Изберете бутон за искате да нулирате в интерфейса за настройка на бутоните, след което щракнете върху „Макро дефиниция“ в падащото меню. Изберете името на макроса и щракнете върху Приложи към завършите настройката.

6.



7.

