



TESSERACT

USER GUIDE

1. Open Case




Unscrew the thumb screws and pull the side panel out as illustrated.




Put power supply on bottom of case and close to rear panel, then lock it with four 6#-32 screws with Phillips screwdriver.


3. 5.25" Drive Bay Installation



LOCK





c. Push the 5.25" drive into the drive bay with proper force. d. Put tool-free lock into place to secure the drive.




a. Secure 2.5" HDD to the rack with one 6#-32 screws, and push it into place. b. Secure 3.5"HDD to the rack and push it into place.

- a. Pick out the standoffs and install them on the motherboard tray. b. Place the motherboard onto the standoffs in accordance with the I/O.
- c. Secure the motherboard using the M3 screws.







a. Loosen the screw to remove the cover and put the

Remove the cover

PCI device in the right direction.

b. Secure PCI device by using the screws.

- a. Use the cable tie and hump on the tray to tidy
- b. A large hole on motherboard tray for easy installation of CPU cooler.

Top: 2×120mm fan Direction: outlet Front: 1×120mm fan Direction: inlet Rear: 1×120mm fan Direction: outlet Side: 2×80mm/90mm/120mm fan Direction: inlet




M3 screws for motherboard and 5.25" Drive Bay 17pcs









Rubber water cooling grommets

ı	Panel Connector	High Definition Audio (Azalia)	USB 2.0 Connector	USB 3.0 Connector
	IDELED+	MIC2_L PRESENSE# HP_R MIC2_JD Jack_Sense No Pin HP_L HP_HD	USB+5V USB_P- USB_P+ USB_P+ GND GND No Pin GND	IntA P2 D+
	Panel Connector	HD Audio Connector	USB 2.0 Connector	USB 3.0 Connector
	POWER PWR SW GND H.D.D IDELED+ IDELED- IDELED- IDELED- PLED-			hadan parameter