



**REDRAGON**  
**HARPE**  
Wired Gaming Keyboard

Wired Gaming Keyboard Operating Instructions

**Dear user**

Thank you for choosing REDRAGON brand. To protect your rights and for better customer service, we ask you note our warranty rules.

1. Within 18 months from purchase date, repair guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot stick) and spare parts replacement, are not included in our warranty.
3. Please fill out the warranty card. Warranty card is valid with the stamp of the retailer.
4. This warranty card will not be reissued if lost. Please keep it in a safe place.

**S.O. support**

Windows XP/Vista/Win7/Win8/Win10

**Features**

1. Ergonomic design
2. 19 n-key rollover
3. Double shot keycap , durable and never removable

**Function Introduction**

1. [FN]+ "☼" for backlighting effect switching: Backlighting off, backlighting on, back to the last setting of backlighting.
2. Back-lighting effect speed adjustment  
FN+"-"/ FN+ "+"/ FN+"." Speed down breathing, FN+"+"speed up , 5 level speed for option, default as 2nd level.
3. [FN]+ "⊞" lock to Windows function, repeat it unlock.  
FN+"WIN", "Win LK LED indicator"will light up, repeat for release and LED light off.
4. Brightness adjustment  
FN+Page Up ,FN+page Down

**Multi-media Function**

- FN+F1 : Media play
- FN+F2 : Volume down
- FN+F3 : Volume up
- FN+F4 : Mute
- FN+F5 : Stop
- FN+F6 : Next track
- FN+F7 : Play/Pause
- FN+F8 : Next track
- FN+F9 : To enter marquee backlight mode: under this mode, cycle 4 marquee back-lighting by press "☼"key.
- FN+F10 : To enter single color backlighting mode: under this mode, cycle 7 Single color backlighting by press "☼"key.
- FN+F11 : To enter mixed color backlighting mode: under this mode: cycle 4 Mixed color backlighting by press "☼"key.
- FN+F12 : Open the calculator

**FAQ**

1. If the keyboard doesn't react, please check if the keyboard interface is correctly inserted into the corresponding USB port in computer, or try to inset the keyboard interface into any other USB port in computer.
2. If you spill liquid on the keyboard carelessly, please pull out the keyboard interface from the computer immediately, wipe out the liquid in the keyboard, and put and dry the keyboard under the sun, and ensure that the liquid in the keyboard has completely been evaporated before use.



Piece parts	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Plastic parts	○	○	○	○	○	○
Metal parts	○	○	○	○	○	○
Circuit components	○	○	○	○	○	○
Cable	○	○	○	○	○	○

**Note:**  
○ = indicates the percentage of toxic or harmful substances in the parts

Our products do not contain toxic or harmful substances and environment friendly, it can be recycled

<b>Name of commodity</b>	Day    Month    Year		
	Warranty is valid within 18 months from the purchase date.		
<b>Customer</b>	Name:		
	Tel:	Zip code:	
<b>Retailer</b>	Address:		
	Name:		Address:
	Tel:	Zip code:	