



REDRAGON VARA

Wired Mechanical Gaming Keyboard

Wired Mechanical Gaming Keyboard (No Light) Operating Instructions

Dear user

Thank you for choosing REDRAGON brand. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

OS Support

Windows XP/Vista/Win7/Win8/Win10

Product feature

1. Plug and play, no driver or software needed.
2. [W][A][S][D] and direction keys exchangeable: Press and hold the [FN] key, and then press the [W] key to interchange the function of four letter keys [W][A][S][D] and four direction keys [UP][DOWN][LEFT][RIGHT]. Repeat the above operation to restore the previous setting.
3. Disable or enable the [WIN] key: Press and hold the [FN] key, and then press [WIN] key to disable [WIN] key in order to avoid leaving gaming function if user presses [WIN] key by mistake. Repeat the above operation to resume the function.
4. Multimedia function: 11 multimedia keys. Access by pressing the [FN] key and one of the [F1]~[F11] keys at the same time.
FN+F1 My Computer
FN+F2 Search
FN+F3 Calculator
FN+F4 Media Player
FN+F5 Previous Track
FN+F6 Next Track
FN+F7 Play/ Pause
FN+F8 Stop
FN+F9 Mute
FN+F10 Volume Down
FN+F11 Volume Up
5. Number Lock/ Caps Lock/ Scroll Lock indications.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboards USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.



尺寸 : 100x100mm
双面印