

USER
MANUAL



Gaming Keyboard



GAMING KEYBOARD

Thank you for choosing this gaming keyboard, please read the user manual carefully when you use this product.

Package Content

- Gaming Keyboard x 1
- User Manual x 1
- USB Cable x 1
- CD Driver (Optional) x 1
- Spare Mechanical Switch (Optional) x 6
- Key Puller (Optional) x 1

System requirement: Compatible with Windows 7, Windows 8, Windows 10, mac OS (not supported in driver).

Product parameters

Connection: Wired	Working Voltage: 5V
Keystroke Lifetime: >50 million	Working Current: ≤100mA
The number of Keys: 87 keys	Cable: 1.7m birded cable

Function Introductions



- FN + F 1 : My computer
- FN + F 2 : Web Home
- FN + F 3 : Calculator
- FN + F 4 : Media Play
- FN + F 5 : Previous Track
- FN + F 6 : Next Track
- FN + F 7 : Play/Pause
- FN + F 8 : End
- FN + F 9 : Mute
- FN + F 10 : Volume -
- FN + F 11 : Volume +
- FN + F 12 : Key Lock
- FN + WIN : Win Lock

Backlight Control
12 kinds of lighting modes can be adjusted. The method of adjusting are as follows.
FN+ESC: Turn on/off the backlight
FN+ : Change lighting modes
FN+ : Backlight brightness + (6 levels)
FN+ : Backlight brightness - (6 levels)
FN+ : Backlight changing speed -(6 levels)
FN+ : Backlight changing speed +(6 levels)

1. Installation
Install the driver from the CD in the package, or you can download it from:
<http://www.deluxworld.com/en/service/download/>

2. Driver Setting

A. Light Setting
Adjust the bright and speed of the backlight, and click OK to reserve the light mode setting than click apply.



B. Button Setting
Click one key that you want to modify, then choose the functions among default, key, multimedia, and macro.



Key
Input any key definition, for example input "b", click "OK" then "Apply"



Multimedia
Choose "Multimedia" and select one multimedia function, Click "OK" and "Apply".



Macro
Choose Macro and select the created macro, Click "OK" and "Apply".
Note: To create new macro setting, please see "Macro Setting" for details.
B. Macro Setting
Click "Macro Manager" in the main interface. Click "+" to create a new Macro, the default name of macro is Macro 1



Click "Recording" to start. Input keys then click stop to finish.



Usage and Precautions

- This gaming keyboard is a precision product.
- Pay attention to clean the dust regularly, to extend the lifetime of the switch.
- Pay attention to moisture proof, because of the electronic PCB, water wet easy to cause the product damage.
- Pay attention to not break down when using, violence using is the main factor to reduce the lifetime of such kind product.
- Pay attention to anti exposure when using, strong sunlight can cause the keyboard shell color faded.

Ръководство на потребителя

FCCE

Геймърска клавиатура

Ръководство на потребителя

DELUX

KM13UM

Геймърска клавиатура

Благодарим ви, че избрахте геймърската клавиатура. Моля, прочетете внимателно ръководството на потребителя.

Съдържание на пакета:

1x Геймърска клавиатура

1x Ръководство на потребителя

1x USB кабел

1x CD с ресурси

Системни изисквания:

Съвместимост с ОС: Win 7/8/10

Параметри на продукта:

Свързване: с кабел	Работен волтаж: 5V
Живот на клавишите: 50 млн.	Работен ток: <100 mA
Брой клавиши: 87	Кабел с дължина 1.7 м

1.

2.

Function Introductions

FN + F 1 : My computer
FN + F 2 : Web Home
FN + F 3 : Calculator
FN + F 4 : Media Play
FN + F 5 : Previous Track
FN + F 6 : Next Track
FN + F 7 : Play/Pause
FN + F 8 : End
FN + F 9 : Mute
FN + F 10 : Volume +
FN + F 11 : Volume -
FN + F 12 : Key Lock
FN + WIN : WIN Lock

Backlight Control

12 kinds of lighting modes can be adjusted. The method of adjusting are as follows.
FN+ESC: Turn on/off the backlight
FN+ [] : Change lighting modes
FN+ [] : Backlight brightness + (6 levels)
FN+ [] : Backlight brightness - (6 levels)
FN+ ← : Backlight changing speed + (6 levels)
FN+ → : Backlight changing speed - (6 levels)

1. Инсталиране на драйвърите

Инсталирайте драйвърите CD диска в пакета, или посетете <http://deluxworld.com/en/service/download>

2. Настройка на драйвъра

А. на осветеността

Настройте яркостта и скоростта на осветлението, натиснете ОК, за да запазите настройките.

3.

4.

Б. на клавишите:

Натиснете клавишът, който желаете да промените, изберете функция между - мултимедия/по подразбиране.

5.

6.

Мултимедия

Натиснете „мултимедия“ и изберете мултимедийна функция. Изберете потвърди, за да запазите промените.

7.

8.

Макро

Отидете на таб „макро“, за да създадете макро функция и натиснете ОК.

В. Настройки на макро

Отидете на „Macro manager“ от главния интерфейс, натиснете +, за да създадете нова макро функция и въведете име в полето

9.

11.

Употреба и предпазни мерки:

Тази геймърска клавиатура е прецизен продукт. Обърнете внимание да почиствате редовно, за да удължите живота на суучовете. Обърнете внимание на влагоустойчивостта, поради електронната печатна платка, намокрена с вода лесно може да причини повреда на продукта. Обърнете внимание да не счупите, когато използването на усилие е основният фактор за намаляване на живота на такъв вид продукт. Обърнете внимание на защитата от излагане, когато използвате силна слънчева светлина, тъй като цвета на корпуса на клавиатурата избледнява.