



VERTICAL



M910GB

USER MANUAL

Thank you for choosing this vertical mouse, please read the user manual carefully when you use this product.

Content



Mouse




User Manual



Battery

Button Function



1	DPI shift
2	Scroll Wheel
3	Right Button
4	Left Button
5	One click to surf the Internet
6	Volume Up
7	Volume Down
8	Forward
9	Backward

Usage

The mouse and USB receiver have already been built up the connection. Please install the battery (1*AA) into the mouse in the correct direction, and insert the USB receiver into the USB port of your computer. After detecting ok the mouse can work normally.

Build Up The Connection Between Mouse and Receiver

In case the connection is lost, please build up the connection again between mouse and receiver by followings:

1. Make sure you have installed the battery in the correct direction. Press the middle button (scroll wheel) and switch to be ON mode, the indicator LED light will flash.
2. Insert the receiver into your computer by USB port.
3. After the indicator LED light flashes for 3~5 seconds, it will go off, then the connection is finished.

Debugging Tips

1. Please check if the receiver inserted into the computer.
2. Please check if the power is in the ON mode.
3. Please check if the battery in the correct direction.
4. Please check if the battery enough.
5. Please shorten the distance between the mouse and receiver.
6. Please re-build up the connection between the mouse and receiver.

Working Environment

- The radio signal can penetrate lignin, glass and other the non-metallic objects, realizing 360 degree free transmit, however, it can not penetrate the metal materials. So please not put the mouse, keyboard and the receiver onto the metallic tabletop. The ideal distance is above 20 CM.
- Please be sure there is no big metal between the mouse and receiver, otherwise the connection will be affected; for desktop, USB extending port or front-set USB port is better.
- The receiver should be far away from the monitor, outside disc driver or other electronic products. 20 CM distance is suggested in order to prevent the radio disturbance produced by other electronic products.
- Laser mouse is suitable for operating media wooden, paper or cloth, but not for the lens cover, such as glass and smooth rubber. A mouse pad is needed in such environment.
- The standardized receiving distance we offered is under certain radio disturbance environment, the normal environment are better, the actual receiving distance is higher than standardized, but if mix-machine, motor, electric drill and other strong electronic equipments operating nearby, which may lead to slowly receiving or other abnormality.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



M910GB

РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ

Благодарим ви, че избрахте тази вертикална мишка. Моля, прочетете внимателно ръководството на потребителя, когато я използвате.

Съдържание на пакета:




Мишка



Ръководство



Батерия



1	DPI shift
2	Scroll Wheel
3	Right Button
4	Left Button
5	One click to surf the Internet
6	Volume Up
7	Volume Down
8	Forward
9	Backward

Употреба

Мишката и USB приемникът вече са изградили връзката. Моля, инсталирайте батерията (1*AA) в мишката в правилната посока и поставете USB приемника в USB порта на твоят компютър. След като открие OK, мишката може да работи нормално.

Създаване на връзка между мишката и приемника

В случай, че връзката се загуби, моля, изградете отново връзката между мишката и приемника като:

1. Уверете се, че сте инсталирали батерията в правилната посока. Натиснете средния бутон (скролера) и превключете в режим ON, индикаторната LED светлина ще мига.
2. Поставете приемника в USB порт на компютър.
3. След като светлинният индикатор мига за 3~5 секунди, той ще изгасне, след това връзката е завършена.

Съвети за отстраняване на грешки

1. Моля, проверете дали приемникът е поставен в компютъра.
2. Моля, проверете дали захранването е в режим ВКЛ.
3. Моля, проверете дали батерията е в правилната посока.
4. Моля, проверете дали батерията е достатъчна.
5. Моля, съкратете разстоянието между мишката и приемника.
6. Моля, изградете отново връзката между мишката и приемника.

Работна среда

Радиосигналят може да проникне през стъкло и други неметални предмети, реализирайки 360 градусово свободно предаване, но не може да проникне в метални материали. Моля, не поставяйте мишка, клавиатура и приемник върху метални повърхности. Идеалното разстояние е отгоре ~20 см. Уверете се, че няма голям метал между мишката и приемника, в противен случай връзката ще има смущения; за настолни компютри, USB удължаващ порт или преден USB порт е по-добър избор.

Приемникът трябва да е далеч от монитора, външни дискове или друга електроника

Препоръчва се разстояние ~ 20 см, за да се предотврати радиосмущение, предизвикано от други електронни продукти.

Лазерната мишка е подходяща за работа с повърхности от дърво, хартия или плат, но не и от стъкло или други гладки. В такава среда е необходима подложка за мишка.

Стандартизираното разстояние за приемане, което се предлага, е при определени радиосмущения. В по-добра среда, действителното разстояние на приемане е по-високо от стандартното, но ако е налично различни смущения работещи наблизо, може да се наблюдава бавна или проблемна работа.

FCC директива

Това оборудване е тествано и е установено, че отговаря на ограниченията за цифрово устройство от клас B, съгласно част 15 от правилата на FCC. Тези ограничения са предназначени да осигурят разумна защита срещу вредни смущения в жилищна инсталация. Това оборудване генерира употреби и може излъчва радиочестотна енергия и, ако не е инсталиран и използван в съответствие с инструкциите, може да причини вредни смущения в радиокомуникациите. Няма гаранция за това дали ще възникнат смущения при конкретна инсталация.

Ако това оборудване причинява вреда смущения на радио или телевизионно приемане, което може да се определи чрез завъртане на оборудването изключване и включване, потребителят се насърчава да се опита да коригира смущенията чрез едно или повече от следните мерки

- Преориентирайте или преместете приемната антена.
- Увеличете разстоянието между оборудването и приемника.
- Свържете оборудването в контакт на верига, различна от тази, към която е свързан приемникът.
- Консултирайте се с търговеца или опитен радио/телевизионен техник за помощ.

Това устройство отговаря на ограниченията за излагане на радиация на FCC, определени за неконтролирана среда.

Това устройство отговаря на чл. 15 от директивата на FCC. Работата е предмет на следните две условия: (1) това устройство не може да причинява вредни смущения и (2) това устройство трябва да приема всякакви получени смущения, включително смущения, които могат да причинят нежелана работа.

Внимание!

Всякакви промени или модификации, които не са изрично одобрени от страната, отговорна за съответствието, могат да анулират правото на потребителя от гаранционно обслужване.