


# Vertical Mouse





User Manual

Thank you for choosing this special wireless vertical mouse. Please read the user manual carefully when using this product.

### ► Contents:

- Wireless vertical mouse -----X1
- User manual -----X1
- USB nano receiver -----X1
- CD driver for optional -----X1

### ► Button Function:



- ① Left click
- ② Scroll wheel
- ③ Right click
- ④ DPI cycle
- ⑤ Backward
- ⑥ Forward
- ⑦ ON/OFF button

### ► Features

- Vertical mouse, worm bionic shape design.

### ► Installation

Plug the USB connector for wired mouse (or USB Nano receiver for wireless version) to the USB port in the computer, after detecting successfully it will work normally.

### ► Specification

DPI	800 /1200 /1600
Polling rate	125Hz
Working Voltage	1.5V
Working Current	< 20mA

### ► Receiver Connection

Equipping the mouse with battery, insert the Nano receiver to the USB port of your computer, pushing the ON button on the bottom of the mouse, and the receiver will detect the device automatically, plug and play.

The red light will flash once if you shift the DPI to the first gear, will flash twice when you shift the DPI to the second gear, etc. Also it will flash when the voltage is low.

### ► Driver Instruction

#### 1. Installation

Download the driver from [www.deluxworld.com](http://www.deluxworld.com) or the CD in the package, install the driver.

Note: Please make sure this mouse is already connected to computer when setting the functions in the driver.

#### 2. Setting

These functions can be customized as below.



#### 3. Macro setting:

Click "Assign Macro" to enter into Macro settings, click NEW and name the macro, and click "Left click" on any blank space below MACRO SELECT to confirm the name. Then Start Record, after finishing the record, please click "STOP RECORD", and click "OK" to save the macro. After choosing certain macro, the background of this macro will turn green, you can edit the macro.

#### 4. Other functions:

Basic: Cut, Copy, Paste, etc. 8 functions are available.  
Advanced: Switch window, close window, etc. 6 functions are available.

Media: Previous track, next track, stop, etc. 7 functions are available.  
You can also adjust the speed of tracking, double-click and scrolling.

After setting the functions please click "Apply"; if you need default functions just click "Restore Defaults."

### ► Building Up the Connection Between Mouse and Receiver

If your mouse cannot work normally, you can try to build up the connection again between mouse and receiver, as following steps:

1. Take out the Nano receiver from computer and insert again, it will detect automatically for about 15 seconds.
2. Keep the mouse in ON mode and with battery in correct direction.
3. Keep the effective distance within 10 CM between the mouse and receiver.
4. Press the middle button (scroll wheel) and right button at the same time for about 1~3 seconds, then release it. The connection is being built for about 10 seconds.
5. If cannot build up the connection in 10 seconds, please repeat the above steps.


### ► Debugging Tips

- Check the receiver if is connected to the USB port.
- Check the ON/OFF button if in ON mode.
- Check the effective distance between mouse the receiver and shorten it.
- Rebuild up the connection between the mouse and receiver.



# DELUX

## Вертикална мишка M618mini




## Ръководство на потребителя

Благодарим Ви, че избрахте безжичната мишка. Моля, прочетете това ръководство внимателно.

### ➤ Съдържание на пакета:

- 1x Мишка
- 1x Ръководство на потребителя
- 1x USB нано приемник

### ➤ Функции на бутоните:



① Ляв бутон

② Скролер



③ Десен бутон

④ DPI

⑤ Назад

⑥ Напред

⑦ On/Off бутон



### ➤ Характеристики на продукта:

- Вертикална форма

### ➤ Инсталиране:

Свържете USB кабелът (или USB нано приемникът за безжични версии) към USB порт на компютър и изчакайте да се инсталира драйвърът. След това мишката работи нормално.

### ➤ Спецификации

DPI	800 /1200 /1600
Polling rate	125Hz
Working Voltage	1.5V
Working Current	< 20mA

### ➤ Връзка с приемника

Поставете батерия в мишката, свържете нано приемника в USB порта на компютър, натиснете бутона ON в долната част на мишката и приемникът ще открие устройството автоматично. Plug & Play.

Червена светлина ще премигва еднократно, когато натискате бутонът DPI.

Ще присветне 2 пъти за втора предавка и т.н. Също така ще присветва при нисък заряд в батерията.

1.

2.

### ➤ Драйвър инструкции:

1. Инсталиране  
Изтеглете драйвърът от [www.deluxworld.com](http://www.deluxworld.com) и го инсталирайте. Забележка: Уверете се, че мишката е свързана с компютъра.

2. Настройване  
Функциите се настройват както следва:



3.



### 3. Macro настройки:

Изберете „Assign Macro“, за да влезете в Macro настройки. Натиснете „NEW“ и въведете име в полето. След това „Left click“ върху празно пространство под „Macro select“, за потвърждение. Изберете „start recording“ за начало и „stop recording“ за край, след това ОК - за запазване на промените. Слек като изберете макро, фонът му ще оцвети в зелено.

### 4. Други функции:

Стандартни: cut, copy, paste, и др. 8 са налични  
Разширени: смяна на прозорец, затваряне и др. 6 са налични.  
Магия: предна/следваща песен, stop и 7 други са налични.

4.

### ➤ Установяване на връзка между мишка и приемник:

Ако мишката не работи нормално, установете връзка отново чрез следните стъпки:

1. Извадете нано приемника от компютъра и го пхнете отново. Ще се засече автоматично за ~ 15 сек.
2. Дръжте мишката включена и правилно поставена батерия.
3. Спазвайте ефективно разстояние до 10 см.
4. Натиснете скролера и десен бутон едновременно за 1~3 сек. Връзката е установена за ~10 сек.
5. Ако не успеете да свържете до 10 сек., повторете стъпките.

### ➤ Съвети за отстраняване на грешки:

- Проверете дали приемникът е свързан към USB порт.
- Проверете On/Off бутон дали е вкл.
- Проверете ефективното разстояние между мишката и приемникът.
- Свържете отново.



5.