



Vertical Mouse

M618PR



User Manual

Thank you for choosing this wired vertical mouse. Please read the user manual carefully when using this product.

Contents:

Wired vertical mouse	x1
Plam rest	x1
User manual	x1

Button Function:



Features:

- Vertical mouse, worm bionic shape design.
- Scientific ergonomic design with the removable palm rest, to reduce the hand and wrist pain.

Light Mode Switch:

Press middle key and forward key at the same time to switch 11 light mode.

Turn ON/OFF the Light:

Turn on or turn off the light via the Light ON/OFF switch in the bottom of mouse.

1.

DPI Switch:

Press the DPI key to switch DPI among 5 gear: 1000(red light) -2000(green light)-3000(blue light)-4000(purple light)-6200(yellow light)
Press the right key and forward key at the same time for 3s to disable or recover the function of forward and backward key.

Driver setting:

1. Installation

Download the driver from <http://www.deluxworld.com/en/service/download/> install the driver.
Note: Please make sure this mouse is already connected to computer when setting the functions in the driver. After installedthe driver, you can proceed basic setting, macro setting.

2. Settings

Open driver setting interface(mouse must be connected, otherwise driver software unable to be opened), proceedingbase setting, macro, advanced setting.

Button setting

Click the buttons on the top left corner of the software interface, can proceed rolling up, roll down, triple shot, fire key, combination key, macro definition, disable key, DPI key, multimedia function,DPI lock and other function settings.

Marco setting

Click "Macro Editor", entering the macro setting interface, click "new macro" , input macro name, then select " macro name" , clicking "start recording macro", during the recording process, you can enter the required keys on the keyboard, then click "stop recording macro".

Operation instructions after entering Marco edition interface: select the key you want to set, click "macro definition" in the drop-down menu, select the macro name, click "apply", then setting successfully.

2.



DPI setting

On the right side of the interface, click" DPI Setting" to adjust DPI gear, DPI value modification, wheels and logo lighting color setting .

3.



Lighting setting

On the right side of interface, click" lighting setting" to adjust the lighting effect of the mouse bottom, choosing different lighting effect, can make the mouse bottom appear different lighting effect. Users can adjust brightness,speed, color of the lighting.



4.

Mouse parameter setting

On the right side of the interface, click" mouse parameter" to adjust mouse sensitivity, speed, double click speed, after finished adjustment, click" apply" ,then completed setting.



Mouse rate setting

On the right side of the interface, click" mouse parameter" to adjust mouse sensitivity, speed, double click speed, after finished adjustment, click" apply" ,then completed setting.



5.



6.



Вертикална мишка

M618PR



Ръководство на потребителя

Благодарим ви, че избрахте тази вертикална мишка. Моля, прочетете внимателно ръководството, преди да я използвате.

Съдържание на пакета:

- 1x Кабелна Вертикална мишка
- 1x Подложка за китки
- 1x Ръководство на потребителя

Функции на бутоните:



① ляв бутон	⑤ назад
② десен бутон	⑥ подложка за китки
③ скролер	⑦ подсветка Вкл./Изкл.
④ напред	⑧ DPI бутон

1.

Характеристики на продукта:

- ▶ Вертикална мишка с ергономичен дизайн
- ▶ Подвижна подложка за китките, намаляваща напрежението в ръцете.

Превключване на подсветката:

Натиснете едновременно средния бутон и напред за 11 светлинни режима.

Изключване на подсветката:

Натиснете бутон Light On/OFF в долната част на мишката в положение OFF.

Промяна на чувствителността:

Натиснете DPI бутон за избор измежду 5 режима на чувствителност: 1000 (червена LED); 2000 (зелен LED); 3000 (син LED); 4000 (лилав LED); 6200 (жълт LED).

Натиснете едновременно за 3 сек. бутони: десен+напред за забрана на подсветката или да възстановите функциите назад-напред на бутоните.

2.

Настройване на драйвърите:

1. Инсталиране

Изтеглете драйвъра от сайта:

www.deluxworld.com/en/service/download/ и инсталирайте.

Забележка: Уверете се, че вече сте свързали мишката с компютър.

2. Настройване

Отворете интерфейса за настройване и следвайте стъпките, докато получите желаните настройки.

Настройване на бутоните

Кликвайки от левия ъгъл на потребителския интерфейс може да настроите макро режими, скролиране нагоре-надолу, мултимедийки функции и т.н.

Макро бутони


Изберете „Macro Editor“ от потребителския интерфейс, за да добавите нов макро режим, чрез „new macro“, въведете име, след което натиснете „start recording macro“. За да завършите и запаметите макросите натиснете „stop recording macro“.

3.

Инструкции за работа след влизане в интерфейса за редакция на макроси: изберете бутон, който желаете да зададете, щракнете върху "макро дефиниция" в падащото меню, изберете име на макроса и щракнете върху „Apply“, за да запазите промените.



4.



Настройки на чувствителността:

От дясната страна на потребителския интерфейс изберете „DPI settings“, за да настроите степеня на чувствителност, подсветката и цветовете на скролера и Delux логото.



6.

Настройки на подсветката:

От дясната страна на потребителския интерфейс изберете „lighting settings“, за да настроите ефекта на осветление в долната част на мишката. Може също да се настрои яркостта, цвета и скоростта на подсветка.



Настройки на параметрите:

От дясната страна на потребителския интерфейс изберете „mouse parameter“, за да настроите чувствителността, скоростта, реакцията при двоен клик. След като настроите натиснете „apply“, за да запазите промените.

7.



8.

