



1 Connect to a Computer

Option 1: Directly

Wireless USB Adapter



Option 2: Via the USB Extension Cable
(if provided)



Images are for demonstration only.

2 Install Driver



- Go to **My Computer** or **This PC**.
- Double click the **TP-Link** disk then run **SetupInstall.exe** to install driver.




Note:

If you cannot find the setup program, please download the driver at www.tp-link.com/support.

3 Join a Wireless Network

- Click the network icon ( or ) on the taskbar.
- Select your Wi-Fi network, click **Connect** and enter the password when prompted.



Troubleshooting



If you have problems during the installation, please refer to the following online FAQs.

- T1. Can't find the hardware version of the adapter:**
<https://www.tp-link.com/faq-46.html>
- T2. Can't find or connect to the wireless networks:**
<https://www.tp-link.com/faq-2253.html>
- T3. Can't install the driver:**
<https://www.tp-link.com/faq-2252.html>

For technical support, replacement services, user guides, and other information, please visit <https://www.tp-link.com/support>, or simply scan the QR code.



- Do not attempt to disassemble, repair, or modify the device.
- Do not use the device where wireless devices are not allowed.
- Keep the device away from water, fire, humidity or hot environments.
- This USB Adapter can only be powered by computers that comply with Limited Power Source (LPS).