



Installation Guide


InSight Series Bullet Network Camera


*Images may differ from actual products. InSight S345S is used for demonstration in this guide. @2024TP-Link 7106511888 REV1.1.2







2. Mount Camera












3. Install microSD Card (Optional)






4. Connect Alarm Device (Optional)













5. Waterproof Cables (Optional)







6. Activate and Access Camera



More Information

- Web configuration: The default web login address is https://192.168.0.60.
- For more details on installation and setup, scan the following QR codes:





Setup Video

Quick Start Guide

- Safety Information

 Do not use any other chargers than those recommended.

 Do not use damaged charger or USB cable to charge the device.

 Do not use damaged charger or USB cable to charge the device.

 Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.

 Adapter shall be installed near the equipment and shall be easily accessible.

 Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.

EU Declaration of Conformity
TP-Link hereby declares that the device is in compliance with the essential requirements and other r
2011/65/EU and (EU)2015/668.3
The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce/

WK Declaration of Conformity
TP-Link hereby declares that the device is in compliance with the essential requirements and other
Regulations 2016 and Electrical Equipment (Safety) Regulations 2016.
The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca