

M7750 Setup Guide

Model: M7750

Welcome! To ensure equal access for all users, we offer this setup guide. This guide is designed to meet accessibility needs. It will introduce the appearance of your Mobile Wi-Fi and then guide you through the initial configuration process.

Our tpMiFi app and web management page also offer accessibility features, such as increasing page contrast, switching to landscape mode and increasing font size. You can enable them during setup to make it much easier to set up your device and adjust settings! For more accessibility guidance, refer to [Accessibility Support](#).

Note: For some models, Accessibility features will be supported by subsequent firmware upgrades.

Step 1. Know about your Mobile Wi-Fi

This section introduces the package content and product appearance.

1. Package Contents

Mobile Wi-Fi: This small device is usually rectangular and smooth, featuring buttons, a screen or indicator lights.

Battery: The battery is rectangular or square, and has contact points on the bottom.

USB Cable: The cable has a flat nearly rectangular connector on one end and a small flat connector on another. For connecting to the USB port for charging.

2. Product Appearance

Facing the **front side** of the product, there are **2 physical buttons on the right of the top side**, from left to right are the **Menu Button** and **Power Button**.

The USB port is on the bottom side, which is a small and flat port.

The screen is in the middle of the front side.

Turn the product upside down, the **back cover** has a small notch on one corner. You can use this notch to easily remove the back cover.

3. Inside the Battery Compartment

Place the product with the back cover facing up. **Position the notch at the top right** to facilitate the next steps. Use this notch to easily remove the back cover.

There are two card slots in the battery compartment. The one on the left is the **Micro SD Card Slot**. The one on the right is the **Nano SIM Card Slot with a small cover**. The recessed space below the back cover is the battery compartment.

The **product label** is below the card slots. **The label contains the serial number, MAC address, IMEI, SSID and Wireless Password.**

The RESET button is above the slots, centered outside the battery compartment, which is a very tiny recessed button that requires a pin to press. With the Mobile Wi-Fi powered on, remove the cover, then use a pin to press and hold the Reset button for more than 5 seconds to reset the mobile Wi-Fi to its factory default settings.

Step 2. Install the SIM Card and Battery

1. Open the back cover.
2. Insert your SIM card into the Nano SIM Card Slot. Slide up the cover of the SIM Card Slot and lift it up, put your SIM card into place with the gold contacts facing down, then put down and slide back the cover.
3. Scan the barcodes on the product label. Note down the 8-digit Wireless Password and the 12-digit MAC address. If the information you scanned is not 8-digit or 12-digit, please scan a few more times.
4. Align the metal contacts on the **battery** with the metal connectors in the battery compartment, then insert the battery into place.
5. Replace the back cover.

Step 3. Connect to the Internet

1. Press and hold the Power button on the right for more than 5 seconds to power on the Mobile Wi-Fi.
2. Connect your smart device to the Mobile Wi-Fi Network TP-Link_XXXX or TP-Link_XXXX_5G. XXXX is the last 4 digits of the MAC address you mark down.
3. To manage the Mobile Wi-Fi easily, you can download the tpMiFi app by scanning the QR code below. Or scan the QR code for APP on the braille card if it has one.



Need Help?

If the problem still exists or you need more Accessibility Support, contact us at <https://www.tp-link.com/support/> for further assistance.

Sign Up for News & Offers

Follow Us

About

[About Us](#)[Corporate Information](#)[Our Security Commitment](#)[Sustainability](#)[Privacy Policy](#)[Ethical Violation Complaint](#)[Accessibility](#)[Contact Us](#)

Press

[News](#)[Blog](#)[Awards](#)[Security Advisory](#)

Learning Center

[Technology Library](#)

TP-Link, Tapo, Kasa, Omada, VIGI, Aginet, HomeShield, and Tapo Care branded products are products of TP-Link Systems Inc. or its affiliates.

Note: Some services and materials may require you to accept additional terms and conditions before access or use.

References to "TP-Link" may include TP-Link Systems Inc., its subsidiaries, or business units within the TP-Link corporate structure, as applicable.

The materials provided, including but not limited to press releases, presentations, blog posts, and webcasts, are current as of the date of publication and may be superseded by subsequent updates.