

DELUX

2.4G Wireless Mouse



User Manual


Thank you for choosing this wireless office mouse. Please read user manual carefully when using this product.

► Contents:

- Wireless office mouseX1
- User manualX1
- USB nano receiverX1
- AA battery(Optional)X1

► Button Function:

- | | |
|-----------------|----------------------|
| 1. Left click | 6. Backward |
| 2. Right click | 7. ON/OFF switch |
| 3. Scroll wheel | 8. AA battery |
| 4. DPI cycle | 9. USB nano receiver |
| 5. Forward | |



► Features

- Vertical shape
- With RGB light
- For home user and business office

► Installation

Plug the USB nano receiver to the USB port in the computer, after detecting successfully it will work normally.

RGB LED Light

Press the forward key and backward key at the same time for 3s to turn on or turn off the RGB light.

► Specification

DPI	1000/1200/1600
Polling rate	150Hz
Working voltage	1.5V
Working current	≤32mA
Compatible system	Windows 8/10/mac OS

► Receiver Connection

Equipping the mouse with battery, insert the nano receiver to the USB port of your computer, pushing the ON button on the bottom of the mouse, and the receiver will detect the device automatically, plug and play.

► Rebuilding up the Connection between Mouse and Receiver

If your mouse cannot work normally, you can try to build up the connection again between mouse and receiver, as following steps:

- 1.Take out the nano receiver from computer and insert again, it will detect automatically for about 15 seconds.
- 2.Keep the mouse in ON mode and with battery in correct direction.
- 3.Keep the effective distance within 10CM between the mouse and receiver
- 4.Press the left button and right button at the same time for about 1-3 seconds, then release it. The connection is being built for about 10 seconds.
- 5.If you cannot build up the connection in 10 seconds, please repeat the above steps.

► Debugging Tips

- Check the receiver if it s connected to the USB port.
- Check the ON/OFF button if in ON mode.
- Check the effective distance between mouse and the receiver, and shorten it.
- Rebuild up the connection between the mouse and receiver.



DELUX

2.4 G Безжична мишка



Ръководство на потребителя


Благодарим Ви, че избрахте безжичната офис мишка. Моля, прочетете това ръководство внимателно.

► Съдържание на пакета:

- 1x Мишка
- 1x Ръководство на потребителя
- 1x USB нано приемник

► Функции на бутоните:

- | | |
|----------------|------------------|
| 1. Ляв бутон | 6. Назад |
| 2. Десен бутон | 7. On/Off бутон |
| 3. Скролер | 8. AA батерия |
| 4. DPI бутон | 9. Нано приемник |
| 5. Напред | |



1

► Характеристики на продукта:

- Вертикална форма
- RGB подсветка
- Подходяща за домашна и офис употреба

► Инсталиране

Свържете USB нано приемника към USB порт на компютър. След успешно свързване ще работи нормално.

RGB LED подсветка

Натиснете бутони напред и назад едновременно за 3сек., за да включите/изключите RGB подсветката.

► Спецификации

DPI	1000/1200/1600
Polling rate	150Hz
Working voltage	1.5V
Working current	≤32mA
Съвместими ОС	Windows 8/10/mac OS

► Връзка с приемника

Поставете батерия в мишката, свържете нано приемника в USB порта на компютър, натиснете бутона ON в долната част на мишката и приемникът ще открие устройството автоматично. Plug & Play.

2

► Възстановяване на връзката между мишката и приемника:

Ако мишката ви не може да работи нормално, можете да опитате да изградите връзка отново между мишката и приемника, както следва:

1. Извадете нано приемника от компютъра и го поставете отново, той ще открие автоматично за около 15 секунди.
2. Дръжте мишката в режим ВКЛ. и с батерия в правилната посока.
3. Поддържайте ефективното разстояние в рамките на 10 см между мишката и приемникът.
4. Натиснете едновременно левия и десния бутон за около 1-3 секунди, след което ги освободете. Връзката се изгражда за около 10 секунди.
5. Ако не можете да изградите връзката за 10 секунди, моля, повторете стъпките по-горе.

► Съвети за отстраняване на грешки:

- Проверете приемника дали е свързан към USB порта.
- Проверете бутона ON/OFF, дали е в режим ON.
- Проверете ефективното разстояние между мишката и приемника, и го намалете.
- Изградете отново връзката между мишката и приемника.



3