



Gaming Keyboard

SK800GL



User Manual

The Code way

It has been set by the factory in default. You can force to set it by pressing "ESC+K" for 3 seconds if needed. When all the indicators flash, insert the receiver and then complete the matching.

Charging method

(with a 1100mA lithium battery) Insert the USB charging cable. The charging indicator (white light) is always on and it goes off when the charging is completed. The charging current is set to 500~600mA and the estimated time to complete the charging is about 2 hours. The fully charged keyboard can be used for around 10 hours in fully backlight. The keyboard can be used normally during the charging.

Caution

Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.



Thank you for choosing our product. Please read the user manual carefully before using this product.

Package content

Keyboard X1 Manual X1 Type-C Cable X1

Compatibility

Compatible with Windows 7/8/10/Mac OS (No software)

User instruction

1.Connecting way

Bottom switch on,plug the receiver,use it after the device finished matching.

2.Light-changing mode

Click  light key to change lighting mode, light is set by default, it also has breath mode and close mode

Key function

1.FN combination key

FN+F1= open the media	FN+F9= open the internet
FN+F2= volume down	FN+F10= open the mail
FN+F3= volume up	FN+F11= open my computer
FN+F4= turn off volume	FN+F12= open the favorite
FN+F5= last play	FN+PageUp= add the brightness of light
FN+F6= next play	Fn+PageDown= reduce the brightness of light
FN+F7= start/stop	FN+Win= lock the function of Win
FN+F8= turn off	

2.Indicator light icon

 Numeric key indicator light  Shift indicator light  charging/low battery indicator light

Low voltage indicator: when the voltage is lower than 3.2V, the low voltage indicator will flash to remind the user to charge.



Геймърска клавиатура

SK800GL



Ръководство на потребителя

Fn+F11= open my computer
Fn+F12= open the favorite
Fn+PageUp= add brightness of light
Fn+PageDown= reduce brightness of light
Fn+Win= lock the function of Win

2. Индикатор на подсветката

Индикатор за включена цифрова клавиатура

Индикатор за включени главни букви

Индикатор за зареждане/слаб заряд

Индикатор за слаб заряд, когато волтажът в батерията е по-нисък от 3.2V индикаторът ще премигва, напомняйки че трябва да се зареди.

Метод на зареждане

(с 1100mA литиева батерия) Поставете USB кабела за зареждане. Индикаторът за зареждане винаги е включен и изгасва, когато зареждането приключи. Токът на зареждане е настроен на 500-600 mA, а приблизителното време за на зареждане е около 2 часа. Напълно заредената клавиатура може да се използва за около 10 часа с вкл. подсветка. Клавиатурата може да се използва нормално по време на зареждане.

Внимание

Риск от експлозия, ако батерията бъде сменена с неподходящ тип.

Изхвърлете използваните батерии според инструкциите.

Благодарим Ви, че избрахте нашият продукт.

Моля, прочетете внимателно ръководството преди употреба на продукта.

Съдържание на пакета

1x клавиатура 1x ръководство
1x USB Type-C кабел

Съвместимост с ОС

MacOS»Win 7»8»10

Инструкции

1. Свързване
Включете клавиатурата, свържете нано приемника и използвайте, след като устройството се инсталира.
2. Промяна на подсветката
Натиснете върху , за да промените режимите на подсветка. Налични са дишащ и приближаващ режими.

Функции на клавишите

Fn+F1= open media	Fn+F6= next play
Fn+F2= volume down	Fn+F7= start/stop
Fn+F3= volume up	Fn+F8= turn off
Fn+F4= mute volume	Fn+F9= open the internet
Fn+F5= last play	Fn+F10= open the mail

