Setup Guide

Tapo C615G KIT Solar-Powered Pan/Tilt 4G LTE Security Camera Kit

Welcome to the setup guide.

To ensure equal access for all users, we offer this accessible setup guide. This guide is designed to meet accessibility needs, enabling a successful setup. It will introduce the appearance of the solar panel, as well as the camera, including its ports, buttons, and labels, and then guide you through the setup process.

Step 1. Know about your camera

In this section, we will describe the appearance of the solar panel, as well as the camera, including its ports, buttons, and labels.

1. You can find your solar panel, a detachable antenna, and the camera in the package.

Solar Panel: The solar panel is typically a rectangular panel with a power cord and a snap fit on the back. At the end of the power cord, there is a USB Type-C connector for plugging into the camera's charging port to begin solar charging.

Detachable Antenna: The antenna is a flat, long object with an SMA connector on one end. You can install it on the antenna connector of the camera to receive the 4G signal.

The camera is composed of a body with a protruding spherical lens and a base with a flat surface on top.

2. Next, keep the flat surface on the top and the relatively round side of the base facing forward.

To ensure the camera is placed correctly, you should position it with the camera lens facing forward.

3. After positioning your camera correctly, we will introduce the ports, buttons, and labels on your device in a certain order.

Lens: For capturing things within its view.

Light Sensor: It is on the left side of the lens for detecting whether the environment is dark or bright.

Microphone: For capturing your voice. It is on the right side of the lens.

IR LEDs: For creating black-and-white images at night. They are located in the middle, directly above the lens.

White Light LEDs: For creating colorful images at night. They are next to the IR LEDs above the lens.

Motion Sensor: It is below the camera Lens for detecting motion.

Status LED: It is below the motion sensor, showing your camera status. You can check the camera status on the Tapo app.

Tilt the camera lens up to find the speaker.

Speaker: For producing sound, allowing you to hear the audio.

Tilt the camera lens down to locate the silicone cover for the Reset button, Power button, and microSD card slot. Once opened, you'll find the **RESET button** on the left, the **Power button** on the right, and the **microSD card slot** beneath the Power button.

RESET Button: The reset button is a circular, raised button on the left. While the camera is powered on, press and hold the RESET button for 5 seconds to reset the camera.

Power Button: The reset button is a circular, raised button on the right. Press the button for about 3 seconds to turn it on or off.

microSD Card Slot: While facing the front of the camera, insert a microSD card with the notch on the left side, and gold contacts facing the slot.

Underneath the camera base, you can find the **product label**.

Product Label: The product information is partially laser-engraved. The setup QR code, MAC address, and serial number are printed on a sticker.

On the left side of the camera base, you can find the **antenna connector** and the silicone cover for the **Nano SIM Card Slot**.

Antenna Connector: For installing the detachable antenna. It is on the left side of the device, inside a circular depression.

Nano SIM Card Slot: Open the cover. While facing the front of the slot, insert a Nano SIM card with the cut corner on the upper right side for a 4G network connection.

On the right side of the camera base, you can find the silicone cover for the **USB Type-C Charging Port**.

USB Type-C Charging Port: Open the cover for USB charging.

Step 2. Set Up

1. Get the Tapo app from the App Store or Google Play, then log in.

2. Open the cover on the camera body, then press and hold the power button (right) on your camera for about 3 seconds to turn it on. Wait 30 seconds for the camera to start up. You can hear a clicking sound.

3. Tap the + button in the app and select your camera model. Follow app instructions to complete setup.

If you need help, please visit **https://www.tapo.com/support/** for technical support, the user guide, FAQs, warranty & more.

For details on Tapo app accessibility, please check **Accessibility Support**.

English: Safety Information

For Solar Panel:

Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.

Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.

For Camera:

This equipment can be powered only by equipments that comply with Power Source Class 2 (PS2) or Limited Power Source (LPS) defined in the standard of IEC 62368-1.

Do not use damaged charger or USB cable to charge the device.

Do not use any other chargers than those recommended.

Do not use the device where wireless devices are not allowed.

Adapter shall be easily accessible.

Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.

Do not disassemble, repair or modify the product.

Do not place near automatically controlled devices such as fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

Observe restrictions on using wireless products in fuel depots, chemical plants or when blasting operations are in progress.

Do not use liquid to clean the product. Only use a dry cloth.

Never put metal objects inside the product. If a metal object enters the product turn off the circuit breaker and contact an authorised electrician.

This product is not intended to be used when providing medical care. Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids to determine if they are adequately shielded from external RF (radio frequency) energy.

Do not use this product in health care facilities. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Do not place heavy objects on top of the product.

When you leave the product unused for a long time unplug the product from the power outlet.

This product may interfere with other electronic products such as TV, radios, personal computers, phones or other wireless devices.

Operating Temperature: -20°C ~ 45°C (-4°F ~ 113°F)

Adapter should be used indoors where the ambient temperature is lower than or equal to 40°C.
CAUTION!

Avoid replacement of a battery with an incorrect type that can defeat a safeguard.

Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; Do not leave a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

Sign Up for News & Offers   **Follow Us**

| Email Address | Sign Up |

About

About Us

Corporate Information

Our Security Commitment

Sustainability

Privacy Policy

Ethical Violation Complaint

Accessibility

Contact Us

Press

News

Blog

Awards

Security Advisory

Learning Center

Technology Library

Worldwide / English