Table of Contents

About This Guide

Get to Know About Your Extender

Set Up Your Range Extender

FAQ

More Info

Authentication

RE405BE User Guide

About This Guide

This guide provides a brief introduction to BE6500 Wi-Fi 7 Range Extender and regulatory information.

Note: Features available in this range extender may vary by model and software version. Range extender availability may also vary by region or ISP. All images, steps, and descriptions in this guide are only examples and may not reflect your actual range extender experience.

Conventions

In this guide the following conventions are used:

Convention	Description
Underline	Underlined words or phrases are hyperlinks. You can click to redirect to a website or a specific section.
Bold	Contents to be emphasized and texts on the web page are in bold, including the menus, items, buttons and so on.
>	The menu structures to show the path to load the corresponding page. For example, Settings > System Tools > Firmware Upgrade means the Firmware Upgrade page is under the System Tools menu that is located in the Settings tab.
Note:	Ignoring this type of note might result in a malfunction or damage to the device.
Tip:	Indicates important information that helps you make better use of your device.

Get to Know About Your Extender

This chapter introduces what the extender can do and its appearance.

It contains the following sections:

- Product Overview
- Appearance

Product Overview

Eliminate Wi-Fi Dead Zones with Unrivaled Wi-Fi 7

WiFi 7 offers accelerated throughput, lower latency, stronger anti-jamming, and higher efficiency.

Lightning-Fast 6.5 Gbps Dual-Band Wi-Fi 7: 5764 Mbps (5 GHz) + 688
 Mbps (2.4 GHz).[†]

- Multi-Link Operation (MLO): Increases throughput, reduces latency, and improves reliability for emerging applications. \triangle
- 2.5G Multi-Gigabit Ethernet Port: 1× 2.5 Gbps port ensures max flexibility and boosted throughput

Easy Installation & Quick Position

The extender works with any standard wireless router. Instantly connect the extender to a router by pressing the router's WPS button (if available) followed by the extender's WPS button. Alternatively, follow the Quick Setup instructions on the extender's web management page.

Once the extender is connected to a router, you can relocate it to your preferred location with no further configuration required. The intelligent signal light can help to find the best location.

Control at Your Fingertips

Set up and manage your WiFi, including TP-Link routers and range extenders, from your Android or iOS phone with the TP-Link Tether app.

Appearance



Button Description

Button	Description
WPS	Press the WPS button on your host router, and immediately press this
(WPS)	button on the extender for 1 second.
	This LED of the extender should change from blinking to solid on,
	indicating successful WPS connection.
Reset	Use a pin to press the button for 1 second to reset the extender.

8.12.25 r., 15:05 RE405BE User Guide

LED Explanation for Range Extender Mode

You can check the extender's working status by following the LED Explanation table.

Name	Status	Indication	
<u> </u>	On/Off	The extender is on or off.	
(Power)	Blinking	The system is starting up or firmware is being upgraded.	
<u>©</u>	Solid blue	The extender is connected to your router's wireless network and is in a suitable location.	
(Signal)	Solid red	The extender is receiving a weak signal. Try relocating it closer to your host router.	
	Blinking	WPS connection is in progress.	
	Off	No wireless connection is established.	
2.4G	On/Off	The extender is connected or not connected to the	
	0. 1011	2.4GHz wireless network of your host router.	
5G	On/Off	The extender is connected or not connected to the	
		5GHz wireless network of your host router.	
₽	On/Off	The Ethernet port is connected or not connected to	
(Ethernet)		a powered-on device.	

LED Explanation for the Access Point Mode

When the extender works in the Access Point mode, you can check its working status by following the LED Explanation table below.

Name	Status	Indication	
υ	On/Off	The extender is on or off.	
(Power)	Blinking	The system is starting up or firmware is being upgraded.	
	On	A WPS connection is established.	
8	Blinking	WPS connection is in progress. This may take up to 2	
(Signal) minutes.		minutes.	
	Off	A WPS connection has been established for more	
		than 5 minutes or WPS connection failed.	
2.4G	On/Off	The 2.4 GHz wireless band is enabled or disabled.	
5G	On/Off	The 5 GHz wireless band is enabled or disabled.	
<u> </u>	On/Off	The Ethernet port is connected or not connected to	
(Ethernet)		a powered-on device.	

Set Up Your Range Extender


This chapter introduces how to boost your host wireless coverage. Please follow the step-by-step instructions to place your range extender and apply power. It contains the following sections:

- Power On the Extender
- Set Up the Extender

Power On the Extender

- 1. Position your extender next to your Wi-Fi router.
- 2. Plug the extender into a nearby electrical outlet.
- 3. Wait until the Power LED is **solid**.

Note: For safety, only plug the extender in upright direction as shown below.



Set Up the Extender


There are three ways to set up the extender:

- Via the WPS button
- Via the TP-Link Tether app
- Via a web browser

Method 1. Set Up via the WPS Button

Use this way if your router has a WPS button. The button might look like one of these: (9) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4) | (4)

1. Activate the WPS function on your router by pressing the WPS button.



Note: If you don't know how to do it, refer to your router's user manual, or try other methods to set it up.


2. Within 2 minutes, press the WPS button on the extender for 1 second, and the **\Rightarrow** LED starts blinking. Wait for the **\Rightarrow** LED, 2.4GHz, 5GHz LEDs to turn **solid blue**, indicating a successful connection.

Note: If the LED does not turn solid on, try again or try setting up via the TP-Link Tether app or a Web Browser.

8.12.25 г., 15:05

RE405BE User Guide

3. If the extender connects to a dual band router, repeat steps 1 and 2 above to connect to the other band. Wait until the Signal 🕿 LED turns solid on, and the setup is done.




If you cannot find the network names with **_EXT** in your Wi-Fi network list, this means that the extender has been connected to a EasyMesh router and automatically copied its wireless settings.

4. Relocate your extender for optimal Wi-Fi coverage and performance.

Plug in the extender about halfway between your router and the Wi-Fi dead zone. The location you choose must be within the range of your router.

Wait for about **2 minutes** until the Signal LED **a** turns solid blue. If it doesn't, relocate the extender closer to the router to achieve better signal quality.



Tip: To minimize signal interference, please choose a location which is far away from Bluetooth devices and other household electronic devices, such as cordless phones, microwave ovens and baby monitors.

5. Enjoy! Connect your devices to the extender wirelessly or via an Ethernet cable, then enjoy the internet.

Method 2: Via the TP-Link Tether App

1. Launch the Apple App Store or Google Play Store and search TP-Link Tether or simply click the button below to download and install the app.





2. Launch the Tether app and log in with your TP-Link ID.

Note: If you don't have a TP-Link ID, create one first.

- 3. Tap the + icon on the upper-right corner and select **Add a Range Extender**.
- 4. Follow app instructions to set up and relocate your extender.
- 5. Enjoy! Connect your devices to the extender wirelessly or via an Ethernet cable, then enjoy the internet.

Method 3: Via a Web Browser

1. Connect your computer to the extender wirelessly as follows:

For Windows Users

- Unplug the Ethernet cable from your computer (if any).
- Click the Wi-Fi icon on the taskbar and connect to the extender's wireless network:
 TP-Link Extender.

For Mac OS X Users

- Unplug the Ethernet cable from your computer (if any).
- Click the Wi-Fi icon in the top right corner of the screen, and connect to the extender's network: **TP-Link_Extender**.
- 2. Launch a web browser, enter http://www.tplinkrepeater.net or http://192.168.0.254 in the address bar, and then create a password to log in.
- 3. Follow the instructions of the Quick Setup Wizard to connect the extender to your host router.
- 4. Enjoy! Connect your devices to the extender wirelessly or via an Ethernet cable, then enjoy the internet.

FAQ

Q1. How to reset the extender to its factory default settings?

A1: With the extender powered on, use a pin to press the Reset button for **1 second**. The extender will reboot.

A2: Log in to the extender's web management page. Go to **Settings** > **System Tools** > **Backup & Restore** and click **Factory Restore**.

Q2. What should I do if I forget my login password?

A: Refer to **FAQ > Q1** to reset the extender, and then visit **http://www.tplinkrepeater.net** to create a new login password.Note: The extender must be reconfigured after a reset to access the internet. Please note down your login password for future logins.

Q3. What should I do if I forget my wireless password?

A: The extender shares the same wireless passwords as those of your host networks.

More Info

The latest software, management app and utility are available from Download Center at https://www.tp-link.com/support/.

The Quick Installation Guide can be found where you find this guide or inside the package of the extender.

Operating temperature, storage temperature, and other specifications can be found on the product page at https://www.tp-link.com.

Our Technical Support contact information can be found at the Contact Technical Support page at https://www.tp-link.com/support.

Disclaimer

[†]Maximum wireless signal rates are the physical rates derived from IEEE Standard 802.11 specifications. Higher capacity is based on laboratory test data, which analyzed the connections of different devices on the 5 GHz, and 2.4 GHz bands simultaneously. These devices simulated a typical home scenario by running simultaneous applications in the same room that included 4K video, 1080p video, 720p video, file downloading, web browsing, IP cameras, and other IoT devices. Actual wireless data throughput, wireless coverage, and connected devices are not guaranteed and will vary as a result of internet service provider factors, network conditions, client limitations, and environmental factors, including building materials, obstacles, volume and density of traffic, and client location.

[‡]The product may not be compatible with routers or gateways with firmware that has been altered, is based on open source programs, or is non-standard or outdated.

§Uninterrupted Streaming is designed for devices that support the 802.11k/v standard.

 $^{\Delta}$ Use of Wi-Fi 7 (802.11be), Wi-Fi 6 (802.11ax), and features including Multi-link Operation (MLO), 4K-QAM, Multi-RU, OFDMA, and MU-MIMO requires clients to also support the corresponding features.

*TP-Link EasyMesh-compatible products can network with other devices that use EasyMesh. Failed connections may be due to firmware conflicts of different vendors. The EasyMesh-compatible feature is still being developed on some models and will be supported in subsequent software updates. This product is compatible with standardized EasyMesh technology but has not obtained the Wi-Fi EasyMeshTM certification.

**Unified management is available for TP-Link EasyMesh-compatible devices. This feature is not guaranteed for devices from other vendors.

***Wi-Fi generations represent the wireless standard IEEE 802.11 a/b/g/n/ac/ax/be. All devices need to support 802.11 Wi-Fi protocols.

♦ Use of WPA3 requires clients to also support the corresponding feature.

 $^{\dot{x}}$ "4× Lower Latency" refers to the latency improvement of Wi-Fi 7 range extenders compared to Wi-Fi 6/6E range extenders, based on laboratory test data. The test conditions had the same 5 GHz single-frequency wireless interference and tested the maximum latencies of Wi-Fi 7 clients (with MLO turned on) connecting to the 5 GHz bands of RE405BE (with MLO turned on) simultaneously and to the 5 GHz of a Wi-Fi 6/6E range extender (without the MLO function).

Actual network speed may be limited by the rate of the product's Ethernet WAN or LAN port, the rate supported by the network cable, internet service provider factors, and other environmental conditions.

This range extender may not support all the mandatory features as ratified in the IEEE 802.11be specification.

Further software upgrades for feature availability may be required.

Pictures are for reference only. If there are any inconsistencies between the product image and the actual product, the actual product shall prevail.

Authentication

FCC compliance information statement



Product Name: BE6500 Wi-Fi 7 Range Extender

Model Number: RE405BE

Responsible Party: TP-Link Systems Inc.

Address: 10 Mauchly, Irvine, CA 92618 Website: http://www.tp-link.com/us/

Tel: +1 626 333 0234 Fax: +1 909 527 6804

E-mail: sales.usa@tp-link.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be colocated or operating in conjunction with any other antenna or transmitter."

We, TP-Link Systems Inc., has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no

unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2025-07-24

CE Mark Warning



OPERATING FREQUENCY (the maximum transmitted power)

2400 MHz -2483.5 MHz (20dBm)

5150 MHz -5250 MHz (23dBm)

5250 MHz -5350 MHz (23dBm)

5470 MHz -5725 MHz (30dBm)

EU Declaration of Conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863.

The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce/.

RF Exposure Information

This device meets the EU requirements (2014/53/EU Article 3.1a) on the limitation of exposure of the general public to electromagnetic fields by way of health protection. The device complies with RF specifications when the device used at 20 cm from your body.

Restricted to indoor use.

National Restrictions

Frequency band: 5150 - 5250 MHz:


Indoor use: Inside buildings only. Installations and use inside road vehicles and train carriages are not permitted. Limited outdoor use: If used outdoors, equipment shall not be attached to a fixed installation or to the external body of road vehicles, a fixed infrastructure or a fixed outdoor antenna. Use by unmanned aircraft systems (UAS) is limited to within the 5170 - 5250 MHz band.

Frequency band: 5250 - 5350 MHz:

Indoor use: Inside buildings only. Installations and use in road vehicles, trains and aircraft are not permitted. Outdoor use is not permitted.

Frequency band: 5470 - 5725 MHz:

Installations and use in road vehicles, trains and aircraft and use for unmanned aircraft systems (UAS) are not permitted.



UKCA Mark



UK Declaration of Conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.

The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca/.

Attention: This device may only be used indoors in Great Britain.



Canadian Compliance Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1. L'appareil ne doit pas produire de brouillage;
- 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution:

1. The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems; DFS (Dynamic Frequency Selection) products that operate in the bands 5250-5350 MHz, 5470-5600MHz, and 5650-5725MHz.

Avertissement:

1. Le dispositif fonctionnant dans la bande 5150-5250 MHz est réservé uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

Les produits utilisant la technique d'atténuation DFS (sélection dynamique des fréquences) sur les bandes 5250-5350 MHz, 5470-5600MHz et 5650-5725MHz.

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Industry Canada Statement

CAN ICES-003 (B)/NMB-003(B)

Korea Warning Statements:

당해 무선설비는 운용중 전파혼신 가능성이 있음.





Points de collecte sur www.quefairedemesdechets.fr Privilégiez la réparation ou le don de votre appareil!

NCC Notice & BSMI Notice

注意!

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前述合法通信,指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

應避免影響附近雷達系統之操作。

高增益指向性天線只得應用於固定式點對點系統。

安全諮詢及注意事項

請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。

清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。

注意防潮, 請勿將水或其他液體潑灑到本產品上。

插槽與開口供通風使用,以確保本產品的操作可靠並防止過熱,請勿堵塞或覆蓋開口。請勿將本產品置放於靠近熱源的地方。除非有正常的通風,否則不可放在密閉位置中。不要私自拆開機殼或自行維修,如產品有故障請與原廠或代理商聯繫。

限用物質含有情況標示聲明書

設備名稱: BE6500 Wi-Fi 7 Range Extender RE405BE				型號((型式):	
Equip	ment na	ame			Type designation (Type)	
	限用物質及其化學符號 Restricted substances and its chemical symbols					
單 元 Unit	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr+6)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
РСВ	0	0	0	0	0	0
外殼	0	0	0	0	0	0
電源供應板	-	0	0	0	0	0
其他	-	0	0	0	0	0

設備名稱: BE6500 Wi-Fi 7 Range Extender 型號(型式):
RE405BE
Equipment name Type designation (Type)

及
其
配
件

備考1. "超出0.1 wt %"及 "超出0.01 wt %"係指限用物質之百分比含量超出百分比含量基準值

Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.

備考2. "○" 係指該項限用物質之百分比含量未超出百分比含量基準值。

Note 2: "o" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考3. "-" 係指該項限用物質為排除項目。

Note 3: The "-" indicates that the restricted substance corresponds to the exemption.



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.




Safety Information

Keep the device away from water, fire, humidity or hot environments.

Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us

Do not use the device where wireless devices are not allowed.

Make sure the power socket has a good contact with the ground.



ATTENTION:



Double pôle/fusible sur le neutre. Déconnecter du réseau électrique avant toute intervention de maintenance.

Operating Temperature: $0^{\circ}\text{C} \sim 40^{\circ}\text{C}$ ($32^{\circ}\text{F} \sim 104^{\circ}\text{F}$)

This product uses radios and other components that emit electromagnetic fields. Electromagnetic fields and magnets may interfere with pacemakers and other implanted medical devices. Always keep the product and its power adapter more than 15 cm (6 inches) away from any pacemakers or other implanted medical devices. If you suspect your product is interfering with your pacemaker or any other implanted medical device, turn off your product and consult your physician for information specific to your medical device.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

Explanation of the symbols on the product label

Note: The product label is on the back of the product and its power supply. Symbols may vary from products.

Explanation 解釋 Class II equipment Class II equipment Class II abd fi Class II equipment with functional earthing 具有功能接地的Class II abd fi Alternating current 交流電 DC voltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 便服室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有層電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Frame or chassis 機架接地 Caution, hot surface 警告,表面高温 Caution Caution Caution Caution Caution Caution Caution Caution Caution Energy efficiency Marking 能源效率標示 Caution	Symbol	
Class equipment Class equipment Class equipment Class equipment equipment	Symbol	
Class II equipment with functional earthing 具有功能接地的Class II 設備 Alternating current 交流電 DC voltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 僅限室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高温 Caution 警告	符號解釋	
Class II equipment with functional earthing 具有功能接地的Class II 設備 Alternating current 交流電 DC voltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 僅聚室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 VI Energy efficiency Marking 能源效率標示 中rotective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Frame or chassis 機架接地 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		
具有功能接地的Class II 設備 Alternating current 交流電 DC voltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 僅限室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 VII Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高温 Caution 警告 Operator's manual		Class II 設備
Alternating current 交流電 Coltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 僅限室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 VII Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		
DC voltage 直流電壓 Polarity of output terminals 輸出端子極性 Indoor use only 僅限室内使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意, 有觸電危險 VI Energy efficiency Marking 能源效率標示 Protective earth 保護地線 上 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告, 表面高溫 Caution 警告 Operator's manual	النتا	具有功能接地的Class II 設備
直流電壓 ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ Polarity of output terminals 输出端子極性	\sim	
Polarity of output terminals 輸出端子極性 Indoor use only 懂限室内使用 Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高温 Caution 警告 Operator's manual	===	
輸出端子極性 Indoor use only 僅限室內使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 VI Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		
懂限室内使用 Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 是arth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告	() (+)	
Dangerous voltage 危險電壓 Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		Indoor use only
Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		僅限室内使用
Caution, risk of electric shock 注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	L	Dangerous voltage
注意,有觸電危險 Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	1	危險電壓
Energy efficiency Marking 能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	\wedge	Caution, risk of electric shock
能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	77	注意,有觸電危險
能源效率標示 Protective earth 保護地線 Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	(VI)	Energy efficiency Marking
Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	VI	
Earth 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		Protective earth
 地線 Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual 		保護地線
Frame or chassis 機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	I	Earth
機架接地 Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	=	地線
Functional earthing 功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual		Frame or chassis
功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	7	機架接地
功能地線 Caution, hot surface 警告,表面高溫 Caution 警告 Operator's manual	4	Functional earthing
警告,表面高溫 Caution 警告 Operator's manual	(-	
警告,表面高溫 Caution 警告 Operator's manual	<u></u>	Caution, hot surface
警告 Operator's manual	<u> </u>	
警告 Operator's manual	A	Caution
1 1 1 1 1	<u> </u>	
1 1 1 1 1		Operator's manual

8.12.25 r., 15:05 RE405BE User Guide

Symbol	Explanation
符號解釋	解釋
	Stand-by 待機
	"ON"/"OFF" (push-push) 「開」/「關」 (按壓式)
=	Fuse 保險絲
→ N	Fuse is used in neutral N 保險絲用於中性線N
	RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment. 回收利用 本產品標示有「廢棄電氣電子設備(WEEE)」的分類回收標誌。這表示本產品必須依據歐盟指令 2012/19/EU 進行妥善回收或拆解,以減少對環境的影響。 使用者可選擇將本產品交給合格的回收機構,或在購買新電器或電子設備時,交回給零售商進行回收處理。
	Caution, avoid listening at high volume levels for long periods 注意,避免長時間以高音量收聽
	Disconnection, all power plugs 斷開所有電源插頭
m	Switch of mini-gap construction 微間隙結構的開關
μ	Switch of micro-gap construction (for US version) Switch of micro-gap / micro-disconnection construction (for other versions except US) 微小間隙結構開關(適用於美國版) 微小間隙 / 微小斷開結構開關(適用於美國以外的其他版本)
ε	Switch without contact gap (Semiconductor switching device) 無接點間隙開關(半導體開關裝置)

8.12.25 r., 15:05 RE405BE User Guide

Sign Up for News & Offers

Follow Us

Email Address Sign Up

About Press Learning Center

About Us News Technology Library

Corporate Information Blog

Awards

Security Advisory

Sustainability
Privacy Policy

Ethical Violation Complaint

Our Security Commitment

Accessibility Contact Us

©2025 TP-Link Systems Inc. and its affiliated companies. All rights reserved.

TP-Link, Tapo, Kasa, Omada, VIGI, Aginet, HomeShield, and Tapo Care branded products are products of TP-Link Systems Inc. or its affiliates.

Note: Some services and materials may require you to accept additional terms and conditions before access or use. References to "TP-Link" may include TP-Link Systems Inc., its subsidiaries, or business units within the TP-Link corporate structure, as applicable.

The materials provided, including but not limited to press releases, presentations, blog posts, and webcasts, are current as of the date of publication and may be superseded by subsequent updates.

Worldwide / English