


Baseus倍思

Baseus True Wireless Earphones Bowie E2

User Manual

Please read the manual carefully before using the product and keep it with proper care for future reference.

**1. Product Appearance****Music Mode**

Double-click left or right earphone (L or R): play/pause
Triple-click left or right earphone (L or R): activate voice assistant (Siri)
Long press the right earphone 1.5 seconds: next song
Long press the left earphone 1.5 seconds: previous song

Call Mode

Double-click left or right earphone (L or R): answer/ hang up
Long press 1.5 seconds left or right earphone (L or R): reject a call

Low Latency Mode Switch

After open the app and add a device successfully, please enter gesture setting. Turn on the low latency button to enable low latency mode and switch off voice assistant with three times of beep to indicate that first setting of the mode finishes. Afterwards switch on/off the mode by triple tapping the left or right earphone, or turn off the low latency button to disable low latency mode with two times of beep. Then switch on voice assistant by triple tapping the left or right earphone.

Battery Status

Press the button on the charging case once to display the current battery level of the case:

White light on means 20%-100% remaining

Red light on means less than 20% remaining

Restore Factory Settings


Put the earphones back into the charging case. Press and hold the button for 5s until the indicator flashes in red and white alternatively for 3 times and turn off the case for restoring factory settings.

2. Product Operation Instruction**2.1 Turn on**

The earphones automatically turn on after open the lid of the charging case.

2.2 Pairing

Turn on phone wireless to search and pair the earphones.

2.3 Wireless connection**2.4 Download the app and link the earphones****Scan to view User Manual****2.5 Turn off**

Put the earphones into the charging case and close the lid to turn off the earphones.

**3. Product parameter****Name:** Baseus True Wireless Earphones**Model No.:** Baseus Bowie E2**Material:** ABS+PC**Version:** V.2**Communication distance:** 10m**Music time:** About 7 hours (70% of the volume)**Music time with a charging case:** About 25 hours**Battery capacity:** 40 mAh/0.148 Wh/earphones/300 mAh/1.11 Wh/charging box**Earphone rated input:** DC5V=7mA**Charging case rated input:** DC5V=50mA**Earphone rated current consumption:** 8mA**Charging case rated current consumption:** 10mA**Charging time:** About 1.5 hours**Frequency response range:** 20Hz-20kHz**Charge interface:** Type-C**State of fit:** Compatible with wireless devices**5. Product safety information**

Please read all instructions and warnings before using this product. Non-standard use will damage the product or personal safety.

If the equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

1) Make sure that the earpiece is clean and water-free.

2) Make sure that the earpiece touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

6) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

7) How to turn on the earphones for better sound quality?

1) Ensure that the earphone has some battery left and you are within 15m of the specific address.

2) The effective duration of search function is about 35 hours. Please use the function for searching missing earphones as soon as possible.

3) In order to record the location of earphones, the app must keep running in the background.

4) When looking for an earphone through the app, try to keep the environment silence as much as possible.

5) The earphone may be in a strong electromagnetic environment, so it cannot receive the signal from the app.

6.2 Will the app reveal my information?

A: No, the app only records the address data of earphones for location function and does not access the users' personal information on the phone. Please be rest assured.

6.3 Why the earphones cannot be turned on/off?

1) Make sure that the charging case and the earphones have battery left, open the lid of the charging case and the earphones will automatically turn on.

2) Make sure that the charging case have battery left, put the earphones back in the charging case, and close the lid to turn off the earphones automatically.

3) When the charging case is out of battery, please turn off the wireless function on your phone and the earphones will turn off automatically in 5 minutes.

4) Please keep the charging case of the earphones and logo of the charging case clear, and regularly clean them with dry cloth.

5) Note: this equipment has been tested and found to comply with the limits for Class B digital device.

6) Due to the low latency mode require the mobile phone to enable low latency mode in residential installation, frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

1) Make sure that the earpiece is clean and water-free.

2) Make sure that the earpiece touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

5) Consumer shall be liable for any personal and property damage resulted from their improper use against the user.

The "Baseus" app must keep running in the background so that your phone can receive alerts of the location of earphones. Android phones have automatic shutdown function of application when turn off the screen. If the "Baseus" app is shut down by applications such as Battery Saver, 360 Total Security, Mobile Butler, etc., the location function cannot work properly. Therefore, please add "Baseus" app into the white list on Android phones to keep the app running in the background.

6) Why is the touch function not sensitive?

1) Make sure that the function of the earphones is clean and water-free.

2) Make sure that the finger to touch the earphones are without water or other foreign objects.

3) Make sure that the touch position is correct, and complete the quick double-click or triple-click operation within 0.5s. If it is unable to connect after the above operation, please turn off the wireless function of the mobile phone close to the mobile phone and restore factory settings before connecting.

4) If it is unable to connect after the above operation, please turn off