


INS-3AF-I-G Quick Start Guide

Package Contents



INS-3AF-I-G

Hardware Overview



1 PoE In


Gigabit 802.3af PoE port. Connect this port to an auto-sensing 802.3af PoE Switch. The switch will automatically activate PoE.

INS-3AF-I-G Quick Start Guide

Gigabit 24V passive PoE port. Connect this port to a 24V passive PoE device.

Hardware Installation

1.



2.



Specifications

INS-3AF-I-G	
Dimensions	Ø 30.26 x 95.5 mm (Ø 1.91 x 3.76")
Weight	50 g (1.76 oz)
Network Interface	
PoE In (802.3af)	(1) Gigabit RJ45 Port
PoE Out (24V Passive)	(1) Gigabit RJ45 Port

INS-3AF-I-G Quick Start Guide

Max. Power Output	24V, 0.5A
Power Method	24V Passive PoE (Pairs 4, 5+; 7, 8 Return)
Power Input	48V, 802.3af
ESD/EMP Protection	± 15kV
Operating Temperature	0 to 70° C (32 to 158° F)

Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.

Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
4. Protective bonding must be installed in accordance with local national wiring rules and regulations.

Limited Warranty

ui.com/support/warranty

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

INS-3AF-I-G Quick Start Guide

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

ISED Canada

CAN ICES-3(A)/NMB-3(A)

Australia and New Zealand



Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



WEEE Compliance Statement

Declaration of Conformity

Online Resources



INS-3AF-I-G Quick Start Guide



© 2026 Ubiquiti Inc. All rights reserved.